
Intellislope® Tile Plow Control System

Installation	1
Components and Identification	1
Display	1
Plow Harness	1
Water Management Module	3
GPS	4
GPS Receiver Configuration	4
Create Configurations	4
Configuration Wizard	4
Setup Tile Controller	4
Configuration Setup	4
Implement Offsets	5
Water Management	5
Ongoing Pitch Zero Adjustment	7
Plow Starting Numbers	7
Rule of Adjustments	7
Verify Control	8
Hydraulic Pressure and Hose Hookup	9
Hydraulics Check	9
Roll Calibration	10
Pitch Calibration	10
Look-Ahead Distance	11
Antenna Offsets	11
Topography	11
Topography screen	11
Red, white, blue scheme	13
Brown-Tan scheme	13
Survey	14
About Surveying	14
Surveying With a Vehicle (Not With Plow)	14
Surveying with Plow	15
Managing Surveys	17
Operating Modes	17
Installing with AutoTile®	18
Modify AutoTile Design	19
Switch Start Button	19
Reverse Outlet Command	20
Adjusting Profile to allow Tiling	21
Tile Type	22
Select Tile Product	22
Creating Tile Products	23
Start Depth Message	24
AutoTile in Process	25
Grade Control	26
Running Grade Control	26
Pitch Control	28
Running Pitch Control	29
Diagnostics	30
Devices	30
GPS	31
Lessons Learned and Pitfalls to Avoid	31

Installation

Components and Identification

Display

The InCommand™ display will mount in the cab. Use the provided cables in the cable kit to install power direct to the battery terminals, routing them out of the way, and clear of moving parts. Use the provided zip ties, to secure the cables. Coil excess cables in an area that will not get caught on moving parts. A RAM mount is provided to mount the display in the cab, and allows for flexibility to install where windows and gauges are not obstructed.

Locate the 4001979-3 cable, and route this toward the back of the tractor. For most front wheel assist tractors this cable should reach to the plow harness that is installed on the tile plow. Extension cables are available in 6, 12, and 24 ft lengths for 4-Wheel drive tractors



Plow Harness






Figure 1

Locate cable PN 4003415. This will be mounted on the plow, with the single round cable connector at the hitch. There are 2 weather pack connectors that will connect to the proportional valve. Route the cable as shown below to ensure that moving parts do not pinch cables, extensions, or adapters.



Water Management Module

The module is designed to be oriented so the cable connections face the tractor. This is so the sensors are oriented correctly and work as designed. Use the provided module adapter plate and hardware to secure the module to the plow in the location as shown on the previous page. The label should also face up when installing. See below image.



Make sure to color match the connections from the harness to the module and don't force the connections. This can prevent damage to electrical pins. The round connections on the harness are used to power the GPS receiver. The 3 large and 1 small square connections will connect to the module. The Brown connector will be used for the GPS signal input.

LED (1) and (2)

- Off—CAN BUS is idle
- Flashing Green—CAN BUS communicating
- Blinking Yellow—Active BUS error when other devices are transmitting/receiving
- Solid Yellow—Passive BUS error when no other devices are acknowledging
- Solid Red—BUS Off



LED (Power)

- Off – no power
- Solid Red – Low voltage
- Solid Green – Good power

GPS

Make sure the GPS receiver is mounted over the top of the cutting plane. There will be 2 cables that will connect the GPS receiver to the module, one is specific to the GPS receiver. The other cable connects to the WMC and has a standard connection for all GPS adapters.

Double check to make sure that all connections are made and snug, and all cables are secured and not routed in areas that will be pinched.

GPS Receiver Configuration

For Intellislope® to receive GPS information from the receiver, the receiver needs to be sending out NMEA GGA, VTG, and GSA messages. NMEA is a standardized output that virtually every GPS receiver supports. When connecting non-Ag Leader receivers for use with Intellislope, the customer is responsible for knowing which port they are connecting to the WMC for NMEA output and configuring the output of that receiver.

For all receiver types, make sure that the following messages are turned on and that the receiver has an RTK fixed position.

- **Baud**—19200 or 38400
- **Hz**—5 or 10 Hz
- **NMEA messages**—GGA, VTG, and GSA. Turn off all other messages.
- **Terrain Compensation**—Receivers with built in terrain compensation must disable it, or plow performance issues may occur.

Some Ag Leader receivers connect through different ports. See below for specific models:

- **7500/6500**—Configure the above settings on Port B. Use GGA (Position). Verify StableLoc® and NMEA Talker are turned off.
- **ParaDyme/GeoSteer/GPS2500**—Configure the above settings on Port A. ParaDyme and GeoSteer need to output GGA current. ParaDyme and GeoSteer antenna heights must be set to 0 in the steering vehicle profile.

Create Configurations

Configuration Wizard




OR



The wizard will then guide you through the process of creating a configuration. After finishing the wizard, the complete configuration should now appear on the Configuration Setup screen and is now able to be selected when starting a new field operation.


Setup Tile Controller


Configuration Setup





NOTE! Use the Manage Equipment button to view a list of specific vehicles and implements.

Implement Offsets


Press  to adjust vehicle offsets.

Press  to modify source of speed.




Press  to adjust plow offsets that were setup when creating configuration.

Tip: Location from antenna (horizontal) is the horizontal measurement of the tip to the antenna. An example is if the tip is 24 inches front of the Antenna, you would enter 24 inches and front (as shown).




Water Management



Pitch Plow check box—Check this box only if the machine is a pitch plow (also called cantilever).

If this box is not checked, Pitch Gain, Pitch Zero, Suggested Calibration, and Start Compensation boxes will be grayed out and unavailable.

This setting effects the operation of Intellislope and it is crucial that it is set correctly. When check box is checked, it indicates that the machine being controlled is a pitch plow and the elevation of its cutting edge is determined by the pitch of the plow. This must be un-checked if the machine is not a pitch plow. Parallel link plows and trenchers are both non pitch plows because the elevation of the cutting edge of the machining is directly effected by the hydraulic cylinder displacement. In this case the GPS receiver must move with the cutting edge for proper control.



The following table summarizes the interaction between the pitch plow setting and adjustments on the “Performance Setup Screen”.

Adjustment	Pitch Plow Checked	Pitch Plow Un-checked	Comments
Pitch Gain	Yes	No effect	Pitch Gain only has effect when the system is controlling pitch, and thus only when configured as a pitch plow.
Look Ahead Distance	Yes	No effect	Look Ahead Distance only has effect when the system is using pitch to control elevation, and thus only has effect when configured as a pitch plow.
GPS-Only Gain	No effect	Yes	GPS-Only Gain only has effect when the system is directly controlling elevation in systems where the hydraulic cylinder directly controls elevation (not a pitch plow).
Pitch Zero	Yes	No Effect	Current calibration value to maintain grade
Start Compensation	Yes	No Effect	Setting to combat soil pressure at the start of a tile installation

Pitch Gain—Determines voltages necessary to effectively adjust pitch. It defaults to a value that works well for the Parker proportional valve and most hydraulic system flows and pressure. The gain may be increased for tractors with lower flow and pressure. Setting the gain too high will cause the plow to respond in an unstable and erratic way. The higher the gain the more aggressive the valve responds.

Pitch Zero—Sensor reading that corresponds to level installation. Value will be set automatically after running Pitch Calibration. See [“Ongoing Pitch Zero Adjustment” on page 7](#).

Reset to Default—Resets Water Management Module to default. Settings may need to be re-entered and new calibration required.

Suggested Calibration—Every time a Grade Control or AutoTile® run is completed the system updates this number to indicate the pitch zero during that run. If your plow tends to run low, this number will likely be higher than the pitch zero, so increase the Pitch Zero to match this number if the On Grade indicator signifies the plow running low. Conversely if it runs high, then decrease the Pitch Zero to match this number. It is very important to watch this number to see if the Suggested Calibration number stays close (within 10) of the Pitch Zero. If it is more than 10 off either way, you should lower or raise the Pitch Zero to bring it to the Pitch Zero Suggested Calibration number.

Intellislope® Tile Plow Control System

i NOTE! The suggested calibration and current pitch zero are viewable during operation under the diagnostics button for the Water Management module.

If for any reason the plow was operated in Grade Control or AutoTile mode with the plow out of the ground, then the Suggested Calibration number will be meaningless and should be ignored. Use the button beside the “Suggested Value” and set the Pitch Zero to the “Suggested Value” (the pitch number will be over written with suggested).

Set as Pitch Zero—Sets the Pitch zero to the number provided by the “Suggested Value”.

Start Compensation—At the start of an installation, the cutting edge of the plow tends to drop slightly as the shank contacts the soil. Start Compensation allows the operator to specify an initial upward pitch to offsets this drop. The extra pitch is reduced to zero over the first 2 meters after which it has no effect. Setting Start Compensation to zero is equivalent to turning it off. A typical setting is 2%.

GPS-Only Gain—This gain only applies when the Pitch Plow box is un-checked. It determines how aggressively the system reacts to elevation errors when controlling machines that are not pitch plows.

Value is normally set to 5 or less. Trial and error may be required for best results.

Ongoing Pitch Zero Adjustment

The Pitch Zero may need to be manually adjusted from time to time so that it remains the setting for level installation.

The following may require it to be readjusted:

- Change in soil characteristics in which the plow operates, since soft or wet soil can cause the plow to “slip” relative to its pitch
- Substantial change in grade of the ground in which the plow operates
- Remounting of the module to the plow
- Change in ambient temperature.

i NOTE! The best strategy is to let the On Grade indicator guide any adjustment. See “On-grade indication” on page 28.

Plow Starting Numbers

Soil-Max® Gold Digger Stealth ZD suggested Starting Values	
Pitch Plow	Checked
Pitch Gain	20
Pitch Zero	900-950**
Start Compensation	2%
Up Valve Threshold	28
Down Valve Threshold	28
Look-Ahead Distance	66.9 in
Recommended Pressure	2950 PSI

Soil-Max® Gold Digger 48 in. Plow suggested Starting Values	
Pitch Plow	Checked
Pitch Gain	15
Pitch Zero	900-950**
Start Compensation	2%
Up Valve Threshold	28
Down Valve Threshold	28
Look-Ahead Distance	45 in.
Recommended Pressure	2950 PSI

**This is an average range seen after calibration is completed.

Rule of Adjustments

- If the plow is predominantly tracking below the target (too low), according to On Grade indicator, increase it.
- If the plow is predominantly tracking above the target (too high), according to On Grade indicator, decrease it.
- Otherwise leave it alone.

Even when the Pitch Zero is well adjusted, the on-grade indicator may reflect deviations from on grade, which is normal and expected. The plow tends to round off sharp corners in the target profile. This will cause either high or low indications as it does so.


There is also a certain amount of deviation within a channel about the target profile that is typical as the control system hunts for the target and responds to external disturbances such as driving over rough terrain. The operator should remain aware of the on-grade indicator, and if grade error starts becoming abnormally large or erratic, he should look for any of number of pitfalls which can be giving rise to the problem.

Noise or error in the GPS elevation, noise in the pitch signal, rocks, soft spots, some degree of control system hunting and overshoot, among other things, can cause brief deviations from on grade. Only when the plow is consistently high or low does the Pitch Zero need adjustment.

If any of the following occur, the Suggested Calibration should be ignored:

- Operating in the “Installing” state while the plow is out of the ground.
- Operating in the “Installing” state, while any external force is being applied to the shank, including any of the following:
 - Lifting or lowering using the three-point hitch or wheel frame
 - Not placing the three-point hitch or wheel frame into float during installation
 - Exerting force on the shank by manually extending or retracting a hydraulic cylinder such as the diagonal lift cylinder on a Parallel link plow
 - Operating a Soil-Max pull-type plow too shallow such that the wheel cylinder forces have too large a component in the vertical direction.
- Operating in the “Installing” state when GPS, GPS quality or GPS RTK correction is lost.
- Installing a tile run in Pre-Ripped ground
- Operating in the “Installing” state when the three-point hitch, wheel frame, or raise/lower diagonal cylinder on a parallel link plow is not fully in float.

If any is known to occur, the Suggested Calibration number should be ignored until after the next run.




Verify Control

Verify Control will check to make sure hydraulics are functioning correctly and determine the voltage necessary to move the cylinders.

i NOTE! This may require that you move over a trench to allow the plow shank to move freely, and not overturn or interfere with the ground.

Adjust the Up/Down Valve Thresholds, and then go to the Verify control screen and use the Up/Down arrows. Adjust the up/down threshold values until moving the arrows makes the implement start to respond.

To run the Control Verification, press button and follow instructions on the display.



If the implement responds opposite of the commands (for example if the UP button makes the plow go down). Verify correct hydraulic flow direction and hydraulic hose connections. If hydraulics are correct, switch proportional connectors or valve polarity.

Up Valve Threshold, Down Valve Threshold—These two settings control how much voltage needs to be applied to the valve to cause the cylinder to begin to move. The higher the number, the higher the voltage the system will apply to begin moving the cylinder, and the quicker the response. The lower the value, the more slowly it will move. On the previous screen, use the up and down buttons to see if those values improve response.

Hydraulic Pressure and Hose Hookup

It is critical to have hydraulic pressure when operating the plow. Take care that the hydraulic flow is in the correct direction. On the front of the Soil-Max hydraulic valve near the hydraulic lines you will see a P and T which stand for pressure and tank. The hose that has the pressure on it is the hose that goes into P or the pressure side of the valve. You can normally tell the pressure side by the stiffness and vibration feeling in the hose.

The tractor's accessory oil pressure should be set high and in the detent position. Pitch plows encounter large forces which must be overcome by the cylinders. High hydraulic oil pressure is required to generate these large forces. Setting the oil pressure too low will cause pitch control errors.

When using a Soil-Max Gold Digger tile plow, the minimum recommended pressure setting is 2,600 pounds per square inch and the minimum recommended flow setting is 10 gallons per minute.

If the cylinders neither retract nor extend then one of the following may be the cause:

Problem—No hydraulic pressure is available.

Solution—Tractor must be running, hydraulic detent engaged and hydraulics must be connected to proportional valve.

Solution—Hoses may be reversed or you may have a bad hose connection.

Problem—Harness is not securely connected to both module and hydraulic valve.

Solution—Check that module-side plug is completely inserted and the connector is locked.

Solution—Check that the valve solenoid connectors are fully seated and screwed down.

Hydraulics Check


This is an automated exercise that only applies to implements configured as 'Pitch Plows' that will extend and retract the pitch cylinders in order to correctly set the valve polarity.

This requires that you detent your hydraulics and may require that you move over a trench to allow the plow to move freely, and not overturn or interfere with the ground (suggested to do this away from concrete). Several items are checked during this exercise:

- Module is connected properly
- Cables are secured to the proportional valve correctly.
- Hydraulic flow is set high enough
- Solenoid connections are secured for operation

Roll Calibration

1. Position the vehicle and implement on a level surface.
2. Mark the location where the implement wheels are contacting the ground if it is a pull-type implement. If the implement is a lift mounted, mark the location of the rear wheel of the vehicle.
3. Press the "Set Roll" button to take the first roll sensor reading.



4. Turn the vehicle and implement around to face the opposite direction and place the same wheels on the marks made on the ground in step 2.


5. Press the "Set Roll" to take the second roll reading.

The Calibrated Roll for the implement should now be displayed.

i NOTE! Press the Reset button at any time to start the calibration procedure over.




Pitch Calibration



Pitch calibration number determines sensor reading for level installation. Plow status will read "Not Calibrated" until Pitch calibration is ran. Only after having followed those instructions will you need to adjust this pitch zero number.

After this initial calibration run, the Pitch Zero will be set automatically. From then on, any changes to the Pitch Zero need to be made manually.

To run Pitch Calibration, Press Pitch Calibration button and follow instructions given on the display. When running a pitch calibration, it can take up to 600 ft of level or constant grade ground to complete.




Look-Ahead Distance

This normally does not need to be adjusted on Gold Digger plows following the default value chart. On other plows, start by setting the horizontal distance (in inches) from the tile boot to the shear of the plow. If performance is not optimal, longer distance will smooth out the plow and make it less reactive. A shorter distance will make the plow react quicker but may cause oscillatory “hunting” about the target elevation.

 NOTE! Default valve 66.9 in. for Gold Digger Stealth ZD plows and 45 in. for ZD48 in. plows.

Antenna Offsets




Antenna to Plow Base

Measure the vertical distance straight down from the GPS antenna to the very bottom of the plow (bottom of the skid plate). AutoTile uses this distance to compute the tile trench elevation from the GPS antenna's elevation. Distance affects the depth because it affects how far the plow shear is below the antenna as it is lowered.

Antenna to Tip (Horizontal)—This is the distance from the Antenna to the tip of the plow or cutting edge. If you had a rope hanging straight down from the antenna, it would be the horizontal measurement from the tip to the rope. If the tip was 24 inches in front of the antenna, you would enter 24 in front.

Antenna To Ground—This measurement tells AutoTile how high the GPS antenna is above the ground when surveying. Measure from antenna, straight down to ground when plow is in surveying position. Plow must be completely lifted and plow boot is pitched all the way up.




Topography

From the mapping screen, press “Topography” button to enter the Topography screen which allows user to setup Topography functionality.

The display allows you to record points that can be used to make a reference layer that is relative to the elevation throughout the field. This can provide you with valuable information in regards to the highs and lows of a field when you may not be able to visually tell with the naked eye. Surveying and Tiling operations will probably benefit the most with respect of where to place the mains and laterals in a field.

 ATTENTION!: Requires RTK GPS signal to collect the accurate elevation data.



You can also import data from mapping software such as SMS™ Advanced via .agsetup files.

Topography screen

You are allowed to have multiple topographical elevation surveys for the same field. This can be useful for different applications, for example:

- One topographical survey that is for the entire field. This will give you a greater perspective of the whole field.


- An additional topographical survey, driven at very dedicated portion of the field. This would allow you to have greater elevation detail in certain areas if you need it.

By default the naming that is generated in the display will be Date/Time based. You can export surface elevation data from software packages like SMS Advanced into the display, and those will be tagged with the field name and the date exported (both examples are in the screen shot).

You can also add points to existing topographical surveys and save them.


Only one topographical survey can be active at a time. When exported as an .agsetup or .agdata file, this will be the survey that is exported. Non-active surveys will stay in the display. At any time you can remove an topographical survey, and collect a new one.

- New Survey button
Press to create a new topographical survey
- Add to Selected button
Press to add to an topographical survey
- Minus (-) button
Press to delete a topographical survey
- Enable checkbox
Press to turn topographical reference layer on/off (Enable checkbox functions the same as Topography checkbox in Map Options screen - shown below.)
- Set Active
Select the desired topographical survey from list and use button to set as active.



The topography layer can be turned on/off as a reference layer during any operation using:

- Enable checkbox on Topography screen (shown above).
- Using the Topography checkbox on the Map Options screen.




Intellislope® Tile Plow Control System

If you have RTK GPS reception, you are allowed to collect an elevation survey. This will allow you to collect the Latitude/Longitude and elevation values as you traverse the field.

A point will be dropped every 10 ft as you drive regardless of speed, or direction. If you are collecting during operations like planting or application using AutoSwath™, it will also log points outside the boundary of the field (i.e. through a grassed waterway) to get the most information throughout the field.

During collection of an elevation survey, points will be logged to the file every 10 ft. An on-screen visual will appear in the form of a single black dot (A) every 100 ft.



ATTENTION!: It is critical that the GPS Antenna to ground measurement is correct in your configuration, any error in this measurement, will add to the error in the data logged.

The following are suggestions to get the best possible elevation survey for a given field. Following these recommendations will provide the best results for your field.

- Keep swaths in the field to 62 ft or less, the closer the better.
- Driving a dedicated route at the lowest or highest points in a field (i.e. lengthwise of a grassed waterway, or at the top of a ridge) then traversing the field in regular swaths will provide the best detail of the field.
- If surveying with the tile plow antenna, ensure that the plow is in the fully raised position.
- Driving too fast with mounted plows, can cause bouncing and affect quality.
- Surveying with harvesting equipment can provide streaked maps as the hopper filling and unloading can affect the height of the vehicle, and therefore antenna.

After the survey points have been collected, they will be converted into a surface layer in which you can define the color scheme Red, White, Blue, or Brown-Tan.

You can select the number of legend ranges for your field that will show the areas desired. This theme will be used for each field until changed.

Hues will represent:

Red, white, blue scheme

Darker blue = Lower elevation.


Darker red = Higher elevations.

White will be a transition color between.

Brown-Tan scheme




Dark brown = Lower elevations.

Tan = Higher elevations.



If at any point during collection your GPS correction status changes out of RTK fixed, logging will be suspended.

If you re-acquire the RTK signal, logging will automatically resume.

At any point you can  (pause) or  (stop) collection of the elevation survey, and then  (resume) as needed.

If you forget to stop logging as you leave the field, you will be prompted with the message that data collection is still active, and be given the option to continue logging, or end operation.

 In Odd-shaped fields, the surface rendering of the elevation will connect areas even if you haven't driven through that area.

Survey


About Surveying


AutoTile can make tiling much easier by creating a sophisticated target profile that hugs the topography of the ground at a selected depth. AutoTile requires that a survey is taken, which records the soil elevation profile, before installing tile. The profile is created by driving over the path where the tile will be installed with the Intellislope system in Surveying Mode. The profile is used to create the target profile for tile installation.


Surveying With a Vehicle (Not With Plow)

Surveys may be conducted prior to installation. This allows the flexibility of performing surveys with other vehicles such as ATVs, trucks or utility tractors. The survey log can be saved on a USB drive and transferred to a different vehicle or display for installation. Ensure that the GPS antenna is securely mounted, and that the Antenna Distance To Ground entered in the Machine Setup screen is correct. Survey logs record the elevation of the ground based on this setting. The log will reflect the setting at the time the survey was made. Any change to the Antenna Distance To Ground setting will not take effect until the next survey is performed.

It is also strongly recommended that if doing a survey days prior to installation that the GPS Base station is not moved, or is reset in exactly the same location as when the survey was collected. Failure to have the base in the same location can render the surveys inaccurate, requiring them to be redone.

 Press the Water Management App to begin the field operation wizard. Be sure to choose the correct surveying configuration.

Drive to the location where you want to start the survey and press .




Drive the path where tile will be placed. At the end of the path press .

Confirmation Screen will appear.




Press  to end survey.




Surveying with Plow


When surveying with the installation tractor and plow, the plow must be completely raised so the GPS antenna distance to ground is consistent for every run and matches the Antenna Distance To Ground entered in the display.

For pull type plows, make sure the wheels are all the way down, and the plow shank is pitched up. For mounted, or 3pt mounted plows make sure the linkage is all the way up, and the plow shank is all the way up.

Press  to view Select Mode Screen.

Select Survey mode




Drive to the location where you want to start the survey and press .

“Start Survey” will change to “Stop”.

As you drive, your path will be indicated with a green line.

Try to get as close to the outlet or main connection as possible (whether at the start of the survey, or the end of the survey, doesn't matter), before ending the survey, but do not back up or make a loop around the starting hole while you are still surveying. Drive past the start of installation and near it if possible.




Drive the path where tile will be placed. At the end of the path press .


Confirmation Screen will appear.





Press  to end survey.






Managing Surveys

Press  to view Manage Surveys Screen.

Survey paths are automatically named but the names can be changed by choosing a survey and pressing . Type a name then press  to enter it.

By checking , you will display the installed tile.

An individual survey path can be removed individually using the  button or all survey paths can be removed using the  button.



Operating Modes

AutoTile—Driving over the tile's path to survey it and then display creates optimal tile placement according to guidelines set by user.

Grade Control—Behaves like a laser control system, except that the grade can be changed without relocating or adjusting a laser tripod, and grade breaks are not limited by mast size.

Pitch Control—Fall-back mode for when GPS is temporarily unavailable. (Only available on configuration set to "Pitch Plows")

Each of these modes of operation are described in detail in its own subsection of this section.

 **WARNING!** Hydraulic machinery can cause bodily injury or death!

The Intellislope control system is designed and tested with safety of operation in mind, however, the operators should never assume that they can anticipate the behavior of the system while it is powered. Follow these rules:

Stay away from the controlled machinery. Always ensure that no person is within the range of motion of the controlled machinery while the control system is powered.



If it should be necessary to work in proximity to the machinery, first power off the control system. The system may be powered off using the display or by removing the system harness.


When controlling machinery other than a Gold Digger plow, the operator must exercise good judgment to ensure that the range of motion of controlled machinery is clear while the system is powered.


Turning off the display, or cutting the power by removing the accessory power plug, will remove power from the hydraulic valve solenoids. This will cause the Parker proportional valve, which is standard on the Gold Digger tile plows, to close.


Other components of the machinery, such as hydraulic system elements, have their own safety rules which are outside the scope of this manual, but which you should familiarize yourself with and follow.

Installing with AutoTile®


Press the  button on the map screen and then on the Select Mode screen, select 


and press the 



Selecting  brings up the survey

selection screen. The selected survey will be drawn as a red line on the over-head map shown on the right side of the screen. If a survey has just been completed, it will be selected by default.

Select the desired survey and press  to continue.



Modify AutoTile Design

Minimum Grade—This is used by AutoTile to create target tile profiles. It specifies the minimum grade you wish AutoTile to maintain. 0.1% grade is a common minimum grade. Min Grade affects the target profile that the control system “aims” at. It is normal for some deviation about the target within a channel about the target profile.

Minimum Depth—This specifies the shallowest depth at which you want AutoTile to place tile, at any point in the tile run. Keep in mind that this depth is to the bottom of the trench. You might want to change this distance if you change to a pipe with a larger or smaller diameter.

Maximum Depth—This is used by AutoTile to know how deep the plow can go. You can either use the maximum depth of the plow or use this to limit the depth you wish the plow to run to lower the pull required if ground conditions are difficult.



Target Depth—This is the depth at which AutoTile aims to install the tile (as long as other constraints permit). This is usually in the 30-42 inch range. You should adjust this if necessary to keep your tile above impermeable clays. This depth is to the bottom of the trench.

Switch Start Button

(Start at Top or Bottom of Run)



On the graph display screen, installation always proceeds from left to right. AutoTile assumes you will start at the lower end of the survey, and that the lower end is the outlet of the tile.

If Intellislope shows your vehicle location at the right side of the screen when you want to start installing, press “Switch Start”. The “Switch Start” button switches the starting and ending locations. The ground’s profile will be flipped, and your current position will now appear on the left side of the screen.






Reverse Outlet Command




The “Reverse Outlet” button changes which end the outlet is on. The outlet end is the end of the path towards which the water drains. There is no effect on the ground profile, which remains unchanged. The difference appears in the shallowest and deepest installation profiles, which now are designed to drain in the opposite direction.


As you start installing, you should always progress from the left side of the profile graph to the right side. If your vehicle position indicator is at the right side, press on the profile graph and modify your outlet location and/or your starting location.



You are allowed to start installation at any point along the surveyed path. If the profile graph is as shown on the left, and you start installation, the tile will be placed at a 0.0 grade



Adjusting Profile to allow Tiling

When a solution exists (which depends on the topography and the constraints you have specified)  will be displayed.


The profiles displayed will enforce the “Minimum Grade”, “Minimum Depth” and “Maximum Depth” constraints that you select. The display will create a target profile that maintains Target Depth as much as possible. As you adjust these parameters, the profile will update.


This can be useful in a number of ways. For example, to make the plow easier to pull, you might wish to decrease the “Maximum Depth” constraint as much as possible.

It is possible that no solution exists given the topography and constraints. Here, the system displays the message “2 in of interference at 742 ft” Given the topography and user constraints there is no profile that can be installed that meets all these constraints.



Increase the “Maximum Depth” to 75 in. to create a solution. The shallowest solution requires us to start at least 2.2' deep. Start at this depth or any depth greater.


Press  to accept target profile.




Tile Type

Select Tile Type from drop-down menu.

- Main
- Sub Main
- Lateral






Select Tile Product

Select Product from drop-down menu or create a new product by pressing  and using the following steps.




Creating Tile Products

Press  on the AutoTile Design screen and then press .



Enter a name, tile size, form, manufacturer. Any notes can be added in the memo section.

Press  when complete.



Start Depth Message

The plow may be lowered to any depth at or below the minimum starting depth, when installing from the outlet end, or uphill, as in most cases. Here the plow is still above the starting depth and a warning message, "Minimum starting depth: 23 in." is given.

If your starting point for the install is in a location that is in front of your survey, the "Start Depth message" may be too shallow as it is reported based on the first point of the survey. For example - if the start depth is 34" but you are 30 ft away from the beginning of the survey, you may have to lower to 35" to maintain your grade from the start of install to the start of the survey.

You must be within 65 ft (20 m) of the start of the survey to be allowed to start installation.

Start Install button will be grayed out until plow has been lower to proper depth.

Auto Level—Automatically levels the cutting edge of the plow as it is lowered to its starting position (pitch plow).



If the machine is not configured as a pitch plow, the "Up" and "Down" buttons are used to manually adjust the position of the machine's cutting edge.

Note that the plow depth indicated on the screen is relative to the elevation of the nearest surveyed point, which is not necessarily the same as the depth in the hole, since the surveyed path may have ended some distance from the starting hole.



WARNING! When the plow has been set into the hole, press the "Start Install" button to be ready to start installing.

When pushing AutoLevel make sure people are clear, as the machine will move.




AutoTile in Process

As installation progresses, the progress is marked by a shaded region under the target profile.

If the plow starts substantially below the target depth, the target profile will initially rise at an aggressive pitch to reach its target depth, and then level out.


The overhead map continuously updates to show your current location in relation to the path.




On-grade Indication—Intellislope displays how close the current installation point is to the target elevation.

This is similar to the arrows and on-grade signals displayed on laser masts. The distance off the target profile is indicated in inches shown as high or low. Otherwise “0.0” is displayed on a background of green.

If this indication shows the plow running consistently too deep, or consistently too shallow, (and it is set up as a pitch plow) then the Pitch Zero needs to be adjusted on the Machine Setup screen. Please see the section “Ongoing Pitch Zero Adjustment” for detailed instructions. If you are using a non pitch plow, GPS Gain can be adjusted.



When reaching the end of the survey path, press the “Stop Install” button to finish the run and save the installation log.



To extract the plow, press the “Up” button to manually nose the plow up while pulling ahead to bring the plow out of the ground.





Never try to pick up the plow using the three-point hitch, or the wheel lift frame for a pull type, when it is in the ground. Always pitch the plow up and pull forward. When the cutting edge is close to the surface, use the wheel frame or three-point hitch to raise to transport position.

Grade Control

If you have tiled with a laser, Grade Control should be natural. You select grade and grade break the same as with a laser. Grade Control is very similar in operation. The key advantage is that all adjustments are made in the cab instead of at the transmitter and mast.

Running Grade Control

Press the  button on the map screen and then on the Select Mode screen, select  and press the




“Up” and “Down” buttons—used to raise or lower the cutting edge of the machine before engaging automatic control.

Auto Level—Automatically levels the cutting edge of the plow as it is lowered to its starting position (pitch plow).


Start Install button—Once the cutting edge of the machine has been lowered to its starting position, pressing this button will cause Intellislope to control the Target Grade and Grade Break as the vehicle progresses forward.

When pushing autolevel make sure people are clear, as the machine will move.




Intellislope® Tile Plow Control System

After pushing Start Install, a dialog box will appear to set the starting Target Grade.

Press  to accept Target Grade.

Once grade is accepted, the machine will automatically adjust as it is driven forward.



The image shows two screenshots of the Intellislope Tile Plow Control System interface. The top screenshot shows the 'Target Grade' dialog box with a numeric keypad and a green checkmark button. The bottom screenshot shows the main control screen with a 'Grade Control' panel on the right and a 'Start Install' button at the bottom. The main screen displays a grid with a yellow arrow pointing to a specific location. The 'Grade Control' panel shows a target grade of 0.10% and a current grade of 0.0". The bottom panel shows a graph of the grade profile and various statistics.

Mode:	784	778	771
Install	0	25	50
	75	100	125
	150	175	200
	225		

Distance:	187.0 ft
Total Rise:	7.1 ft
Elevation:	778.2 ft
Avg Grade:	3.81 %

Target—Use this button to select the grade you desire. You can change this setting on the fly, and Intellislope will follow the new grade starting at the point when the Target grade changed.

Use the + and - button to reach the desired value, or press the target button to enter the desired value on a keypad.

If you are installing uphill, you will need to set the target grade to a positive number, if you are driving downhill, use a negative value.

(The laser equivalent to changing this setting would be: stop the tractor, relocate the laser to the new location, adjust it to the new grade, and resume installing.)

Grade Break—This gives you the ability to add a vertical offset to the tile profile which makes the plow run shallower. Use this if you are too deep. The current Target Grade is otherwise maintained. An example of a common use for this is if you had a flat run at 0.1% grade, went up a hill, and then flattened out again. You could leave the grade at 0.1% and then grade break up the hill until you get to where it flattens out.

On-grade Indication—Below the Target button, Intellislope displays how close the current installation point is to the target elevation.

This is similar to the arrows and on-grade signals displayed on laser systems. The distance off the target profile is indicated in inches shown as high or low. Otherwise "0.0" is displayed on a background of green.

If this indication shows the plow running consistently too deep, or consistently too shallow, (and it is set up as a pitch plow) then the Pitch Zero needs to be adjusted on the Machine Setup screen. Please see the section "Ongoing Pitch Zero Adjustment" for detailed instructions.

If you are setup as a Non pitch plow, and you are running too high, you need to adjust the GPS gain as a lower value, if you are running too low, you need to adjust to a higher value.

Noise or error in the GPS elevation, noise in the pitch signal, rocks, soft spots, some degree of control system hunting and overshoot, among other things, can cause brief deviations from on grade. Only when the plow is consistently high or low does the Pitch Zero need adjustment.

Press  to end installation.



To extract the plow, press the "Up" button to manually nose the plow up while pulling ahead to bring the plow out of the ground.




Never try to pick up the plow using the three-point hitch, or the wheel lift frame for a pull type, when it is in the ground. Always pitch the plow up and pull forward. When the cutting edge is close to the surface, use the wheel frame or three-point hitch to raise to transport position

Pitch Control

Pitch Control mode is only applicable for pitch plows. Other types of machinery should not attempt to use this mode.



Pitch Control is a fall-back mode of operation which may be used when GPS is unavailable. Keep in mind that:

- The Pitch Zero must be calibrated and correctly adjusted.
- Always prefer Grade Control or AutoTile mode when GPS is available. Pitch Control mode does not use GPS. It merely holds the plow shank at a specified pitch based off the WMC.
- Do not depend on the installed grade matching the pitch with better than 0.5% accuracy.
- Entering the incorrect pitch with a pull type plow may result in the plow emerging from the ground, and be unsteady, possibly resulting in the plow tipping on its side.
- Always use visual depth and pitch to verify plow operation.



Running Pitch Control

Press the Mode button on the map screen and then select Pitch Control and Install on the Select Mode screen.

Press the  button on the map screen and then on the Select Mode screen, select  and press


the  on the Select Mode screen.



Press Start Install button to begin Pitch Control.

A keypad will be displayed to enter the desired starting pitch. When you accept this starting value, the machine will respond to the display, so ensure by-standards are not in the way.

The “Up” and “Down” buttons will be visible and can be used to move the cylinders prior to starting install. Use AutoLevel to level the plow at the start of the run. If the implement is in the ground, do not use the AutoLevel.




Use + and - buttons to raise and lower pitch or use Target button to enter a numeric value for pitch.

The installation grade will be approximate the plow shank's pitch.

The module slope sensor will match to the provided Target Pitch.

Press  to end Pitch Control.




To extract the plow, press the “Up” button to manually nose the plow up while pulling ahead to bring the plow out of the ground.




Never try to pick up the plow using the three-point hitch or the wheel lift frame for a pull type, when it is in the ground. Always pitch the plow up and pull forward. When the cutting edge is close to the surface, use the wheel frame or three-point hitch to raise the plow to transport position.

Diagnostics

Devices

Press  to open the Devices screens. Technical support may request that you look at these screens for help in diagnosing a problem.






GPS



During your field operation, the GPS (satellite) button in the upper right-hand side of the Status Bar should appear as green, which means you are receiving a differential GPS signal. If this icon appears yellow, you are still receiving GPS but are not receiving a differential signal; and if it appears gray then you have lost GPS. In either case, you should check your GPS settings.

The two buttons on the top left will appear if the display is receiving GPS signals from two GPS receivers (one from plow-CAN, one from vehicle-serial, or Ethernet).



Lessons Learned and Pitfalls to Avoid

The following is a list of pitfalls that we've observed and can degrade performance. Operators should be aware of these to better avoid them, and should be alert to the on-grade indicator and installation profile to detect when these conditions arise. Some are under the control of the operator while others are not, such as hitting rocks and loss of GPS fix or quality. The list is provided on a best effort basis; it may not be exhaustive. Should an installation error occur, it is straightforward to correct by installing a bypass around the affected section of tile.

Extreme Soil Conditions—Hard clay soil, loose already-plowed soil or soft bottoms can interfere with the ability of the shank's trajectory through the ground to be controlled by the shank's pitch. Normal operation requires that the pitch of the shank guide the trajectory. Soil that has been overplowed and is loose does not generate sufficient force acting on the shank surfaces to allow pitch to control the elevation.

Tractor Effects—A tractor effect is an interaction between the tractor and plow that can push the plow off the target. One such effect occurs as the wheels of the tractor pass over a sharp hump, trash from previous plowing or any uneven surface, the plow hitch will be similarly raised or lowered, pulling the plow frame with it. Pitch control will compensate, however the hydraulics can only fill the cylinders so fast, and so they may not keep up. To allow the system to keep up, drive over any uneven surface as slowly as possible.

Low Hydraulic Pressure—Forces acting on the buried plow shank are large. In the face of these forces, the hydraulic cylinders actuating the plow shank must create large forces and thus high hydraulic pressure is required to displace them. Insufficient hydraulic pressure can leave the system unable to adequately control pitch. Lower pressure can also make the plow slower to respond as it slows down the rate at which the hydraulic cylinders fill.

Older tractors may have open-center hydraulic systems in which hydraulic pressure is proportional to engine RPM, so at low RPM there is insufficient pressure. Modern closed-center hydraulic systems are pressure regulated and are not subject to this problem.

Failure to Float the Three-point Hitch or Wheel Frame—The plow needs to float and freely pivot as it goes through the soil. Force exerted from the three-point hitch, or wheel frame on pull type plows will displace the plow from the target depth. Always ensure the three-point hitch, and wheel frame are in the "Float" setting before beginning installation.

Operating Too Shallow—(less than ~20 inches), and Pull-type Plow Down Pressure

Forces bearing upon the top of the shank allow it to drive deeper when required by control logic. When too shallow, this force can be insufficient.

Related to this issue is the down pressure in the wheel cylinders of a pull-type plow. When shallow operation of a pull-type plow is required, the valve setting on the down-pressure cylinders should be lowered. Too much up pressure can also lift the plow up from the target profile.

The down pressure, depth of operation and soil conditions may interact such that some soil may require deeper operation or lower down pressure than other soils.

Driving Too Fast—When an installation is started with the plow much deeper than the target profile, the system will schedule a target that rises rapidly towards the target profile. When this steep section meets the relatively-level target profile, driving too fast can cause the plow to overshoot the target, as the cylinders can only change the plow pitch so fast. Drive slowly when the target profile grade is changing rapidly.

Obstructions—If you encounter a rock or other obstruction in the field use the Stop Tiling button, and end the install. After you have freed the plow from the rock you are now able to continue tiling. If using Grade Control Mode, you can use the Grade Break to raise the target depth to prevent a flow reversal in the tile. If you were using Autotile, re-select the survey, and adjust the depth settings to create a new target depth. This may include lowering the Minimum depth value, lowering the grade, or lowering the max depth value.

Detuned Configuration Parameters—The pitch gain, look ahead distance, valve thresholds, start compensation and pitch zero settings are discussed in "Water Management" on page 10. Low gains and valve offsets can make the plow respond too lazily, and setting them too high can induce instability.

GPS Interruptions—The elevation control is only as good as the ability of GPS to report elevation. Loss of GPS fix or quality, or change in satellite constellation can cause the GPS to report erroneous elevations. If using a battery-powered RTK base station, the battery can run down leaving the unit without correction.

Defective Components—A rusty/dirty hydraulic valve is an example of a bad component that can degrade performance. Of course as with any electro-mechanical system. Ensure that when connecting hydraulic lines to the tractor, that the tips are clean before connecting them. Intellislope components are not immune to failure. Most component failures lead to the system being inoperative, not degraded performance.